

AVIOM

QUICK START

A360
Personal Mixer

Adjust master volume and tone.



● Digital Signal/Limit



Add Reverb and
adjust Tone.



Adjust the
Channel Volume.




Set the Stereo Placement.



Ambience



Profile Select



Select any numbered Channel Button.



QUICK START

To save a mix

- Hold **Save** and press any **Channel Button** or **Instant Mix Recall™** button.

To recall a mix

- Press an **Instant Mix Recall** button or press **Recall** and then a **Channel Button**.

To reduce the volumes of all channels

- Press **Mute** and **Group** buttons together to **Trim All**.

To assign a Dual Profile Channel™

- Hold **Dual Profile Channel** and press any **Channel Button**.

To mute all channels

- Double-click **Mute**.
- Press **Mute** again to unmute.

To adjust the volume of Ambience

- Hold down **Ambience** until **Channel Volume** LEDs blink. Adjust and then release.

Mixer Modes

Pro16	Use with most 16-channel systems
DEFAULT	Pro16e with default channel mapping
PROGRAM	Set up a custom channel mapping
CUSTOM	Mix using a custom channel mapping

